

# SNAP I/O WIRING GUIDE

Form 1403-040427—APRIL, 2004

**OPTO 22**

43044 Business Park Drive • Temecula • CA 92590-3614  
Phone: 800-321-OPTO (6786) or 951-695-3000  
Fax: 800-832-OPTO (6786) or 951-695-2712  
[www.opto22.com](http://www.opto22.com)

**Product Support Services**

800-TEK-OPTO (835-6786) or 951-695-3080  
Fax: 951-695-3017  
Email: [support@opto22.com](mailto:support@opto22.com)  
Web: [support.opto22.com](http://support.opto22.com)

**SNAP I/O Wiring Guide**  
**Form 1403-040427—APRIL, 2004**

Copyright © 2002–2004 Opto 22.

All rights reserved.

Printed in the United States of America.

The information in this manual has been checked carefully and is believed to be accurate; however, Opto 22 assumes no responsibility for possible inaccuracies or omissions. Specifications are subject to change without notice.

Opto 22 warrants all of its products to be free from defects in material or workmanship for 30 months from the manufacturing date code. This warranty is limited to the original cost of the unit only and does not cover installation, labor, or any other contingent costs. Opto 22 I/O modules and solid-state relays with date codes of 1/96 or later are guaranteed for life. This lifetime warranty excludes reed relay, SNAP serial communication modules, SNAP PID modules, and modules that contain mechanical contacts or switches. Refer to Opto 22 form number 1042 for more details.

---

Opto 22 FactoryFloor, Cyrano, Optomux, and Pamux are registered trademarks of Opto 22. Generation 4, ioControl, ioDisplay, ioManager, ioProject, ioUtilities, mistic, OptoConnect, OptoControl, OptoDisplay, OptoENETSniff, OptoOPCServer, OptoScript, OptoServer, OptoTerminal, OptoUtilities, SNAP Ethernet I/O, SNAP I/O, SNAP OEM I/O, SNAP Simple I/O, SNAP Ultimate I/O, and SNAP Wireless LAN I/O are trademarks of Opto 22.

ActiveX, JScript, Microsoft, MS-DOS, VBScript, Visual Basic, Visual C++, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Linux is a registered trademark of Linus Torvalds. Unicenter is a registered trademark of Computer Associates International, Inc. ARCNET is a registered trademark of Datapoint Corporation. Modbus is a registered trademark of Schneider Electric. Wiegand is a registered trademark of Sensor Engineering Corporation. Nokia, Nokia M2M Platform, Nokia M2M Gateway Software, and Nokia 31 GSM Connectivity Terminal are trademarks or registered trademarks of Nokia Corporation.

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

Serial/IP is a trademark of Tactical Software.

# Table of Contents

<b>Introduction</b> .....	<b>1</b>
<b>SNAP Mounting Racks</b> .....	<b>2</b>
Racks Without Terminal Strips .....	3
Racks with Terminal Strips .....	3
<b>SNAP Power Supplies</b> .....	<b>4</b>
Primary Power Supply .....	4
Determining Power Requirements .....	4
Wiring the Primary Power Supply .....	6
Loop Power Supply .....	7
<b>SNAP Brains</b> .....	<b>9</b>
<b>SNAP I/O Modules</b> .....	<b>10</b>
Module Wiring Diagrams .....	10
Digital Input Modules .....	11
Digital Output Modules .....	12
Analog Input Modules .....	15
Analog Output Modules .....	24
Serial Communication Modules .....	27
SNAP PID Module .....	30




# SNAP I/O™ Wiring Guide

## Introduction

This document includes wiring diagram examples for assembling your SNAP I/O system and attaching it to the devices it will monitor and control. The system includes the SNAP brain and SNAP I/O modules mounted on a SNAP rack, powered by a SNAP power supply. (SNAP controllers are not included in this document.)

### *Example: SNAP Ultimate I/O system partly assembled*



This document includes basic wiring information for SNAP racks, power supplies, brains, and I/O modules. For more information, see the data sheet and the installation or user's guide for your specific products.

# SNAP Mounting Racks


SNAP mounting racks can hold a SNAP brain and up to 4, 8, 12, or 16 SNAP modules.

The following table shows SNAP rack and brain compatibility.

Brain Part Number	Compatible Racks	Rack Description
SNAP-UP1-ADS SNAP-B3000-ENET SNAP-ENET-RTC SNAP-WLAN-FH-ADS B3000 SNAP-B4 SNAP-B6 SNAP-HA SNAP-BRS SNAP-BRS-HA SNAP-BRS-HA-J SNAP-B3000-MODBUS	SNAP-B4M	4-module mixed
	SNAP-B8M	8-module mixed
	SNAP-B8MC	8-module mixed, terminal block
	SNAP-B8MC-P	8-module mixed, pluggable terminal block
	SNAP-B12M	12-module mixed (digital in positions 0–7 only)
	SNAP-B12MC	12-module mixed (digital in positions 0–7 only), terminal block
	SNAP-B12MC-P	12-module mixed (digital in positions 0–7 only), pluggable terminal block
	SNAP-B16M	16-module mixed (digital in positions 0–7 only)
	SNAP-B16MC	16-module mixed (digital in positions 0–7 only), terminal block
	SNAP-B16MC-P	16-module mixed (digital in positions 0–7 only), pluggable terminal block
SNAP-UP1-D64 SNAP-ENET-D64 SNAP-PDPRS64	SNAP-D64RS	16-module digital only (limited digital functions)
SNAP-UP1-M64 SNAP-ENET-S64	SNAP-M16	4-module mixed (limited digital functions)
	SNAP-M32	8-module mixed (limited digital functions)
	SNAP-M64	16-module mixed, digital in any position (limited digital functions)
SNAP-UP1-ADS (newer model)	SNAP-N8M	8-module mixed; accommodates remote communication adapter
	SNAP-N12MC	12-module mixed (digital in positions 0–7 only); accommodates remote communication adapter


## Racks Without Terminal Strips

SNAP racks come either with or without a common terminal strip. The following diagram shows a rack without a terminal strip. For this type of rack, all wiring connections are made to the field connectors on the top of each module (wiring diagrams begin on [page 10](#)). A brain is shown on this rack, but the modules have not been inserted yet.



## Racks with Terminal Strips

If your rack has a terminal strip, you can use it for field wiring common connections, such as loop power distribution, or low-current applications. The following diagram shows a rack with a terminal strip (MC rack models); the smaller diagram shows the optional terminal strip with pluggable connectors (MC-P rack models). Terminal strips do not connect to SNAP modules; depending on your application, you may need to install wiring from the terminal strip to the module. (Again, the rack is shown with a brain but with no modules.)



# SNAP Power Supplies

## Primary Power Supply

*NOTE: For a more general discussion of using power supplies with Opto 22 systems, see Opto 22 form #1271, a technical note available on our Web site at [www.opto22.com](http://www.opto22.com).*

SNAP racks use a 5 VDC power source (5 VDC [-0.0, +0.1] at minimum 4.0 Amps recommended). For systems using AC source voltage, the SNAP-PS5 or SNAP-PS5U power supply is recommended. For DC systems, such as those using DC backup power, the SNAP-PS5-24DC offers DC-to-DC power.

In general, we recommend you **use an independent, isolated, regulated power supply locally with each rack**. Local isolated supplies offer these advantages:

- Short supply conductors, which minimize losses
- Power redundancy, so the failure of a single supply causes only a single rack failure, not a total system failure
- Fewer voltage drops and ground loops. (Voltage drops and subsequent ground loops may occur when power is distributed over a large system.)

Always **use a separate power supply for the field side of the I/O**. Using the rack supply for field actuation and monitoring defeats the isolation the I/O module offers and therefore increases the chance of a ground loop within the control system. Additionally, a sudden change of current on the field side can cause undesirable voltage fluctuations that may interfere with the computer's operation.

## Determining Power Requirements

Both the SNAP-PS5 and the SNAP-PS5-24DC power supplies provide 5 VDC power for loads up to 4 Amps. The SNAP-PS5U provides 5 VDC for loads up to 5 Amps. In most cases this power is sufficient for a SNAP brain, a rack, and the associated I/O modules. However, some combinations of modules, especially special-purpose modules, may require additional power. You can use the following tables to help determine power needs for your I/O units.



**Brain Power Requirements**

Brain	Power Req. (Amps)*
SNAP Ultimate brains (all models)	1.000
SNAP Ethernet brains (except SNAP-WLAN-FH-ADS)	0.800
SNAP-WLAN-FH-ADS (Wireless Ethernet brain)	1.500
SNAP Simple I/O brains	0.500
B3000 (serial SNAP brain) SNAP-D64RS	0.500
SNAP-B3000-Modbus SNAP ARCNET brains	1.000
SNAP-B4 SNAP-B6	1.000 1.500 if terminated

\*Current from 5-volt supply

**I/O Unit (Brain, Rack, and I/O Modules) Power Requirements Worksheet**

Item	Number	X Power Req. (Amps)	Total Power Required (Amps)†
SNAP brain (Enter Amps from Brain Power Requirements table)	1		
SNAP-IDC5-SW digital input module SNAP-IDC5-SW-NC digital input module		0.200	
All other digital input and output modules		0.050	
SNAP-AICTD analog input module SNAP-AICTD-4* analog input module All analog output modules		0.150	
SNAP-AIARMS analog input module SNAP-AIVRMS analog input module SNAP-AIMA and AIMA-4* analog input modules SNAP-AITM and AITM-2 analog input modules SNAP-AIMV-4* and AIMV2-4* analog input modules SNAP-AIV and AIV-4* analog input modules		0.170	
SNAP-AIRTD analog input module SNAP-AIR40K-4* analog input module SNAP-AIRATE analog input module		0.190	
SNAP-AIPM power monitoring module*		0.100	
Isolated analog input modules (part numbers ending in -i or iSRC)		0.200	
Serial modules*		0.250	
PID modules**		0.250	
<b>Total</b>			

\* Can be used with SNAP Simple, SNAP Ethernet, and SNAP Ultimate brains

\*\* Can be used with SNAP Ethernet and SNAP Ultimate brains only


† Current from 5-volt supply

**IMPORTANT:** For a SNAP-PS5 or a SNAP-PS5-24DC power supply, the total power required must not exceed 4 Amps. For a SNAP-PS5U, the total power required must not exceed 5 Amps.

## Wiring the Primary Power Supply

Use one power supply per I/O unit. Use 14 AWG wire.

1. Mount the SNAP-PS5 or SNAP-PS5-24DC power supply so that the attached red and black power wires will reach the + and – power terminals on the SNAP mounting rack.
2. Using the power terminals on the SNAP mounting rack, attach the red wire to the + terminal and the black wire to the – terminal. Connect the ground terminal on the SNAP rack to ground.
3. For the SNAP-PS5 (not illustrated): Using the removable input power connector on top of the power supply, apply 120 volts AC power between the two terminals marked “AC.” Connect the ground terminal to ground.
4. For the SNAP-PS5U (not illustrated): Using the removable input power connector on top of the power supply, apply 240 or 120 volts AC power between the two terminals marked “AC.” Connect the ground terminal to ground.
5. For the SNAP-PS5-24DC (illustrated below): Using the removable input power connector on top of the power supply, apply 24 volts DC power between the two terminals marked “±DC.” Connect the ground terminal to ground.



## Loop Power Supply

Some analog modules (SNAP-AIMA, SNAP-AIMA-4, and SNAP-AIMA-i) also require a current loop supply, which can be provided by the SNAP-PS24 or the SNAP-PS24U. Both offer 24 volts of DC loop power, the SNAP-PS24 at .75 A and the SNAP-PS24U at 1.25 A. Follow these steps to wire loop power supplies.


1. Mount the SNAP-PS24 or SNAP-PS24U power supply in a location where the attached output power wires will reach the field connector for SNAP analog modules or, if you are using an MC or MC-P mounting rack, the terminal strip on the rack.

The white and red wire is the positive wire (24 VDC). The white and black wire is the negative wire (24 VDC return).


2. If you are wiring directly to the module, see the wiring diagram for the specific module you are using (page 17 and page 18).

Examples for an input module are shown in the following diagrams.

### SNAP-PS24




### SNAP-PS24U




- If you are wiring to a rack with a field wiring terminal strip (models MC and MC-P), see Opto 22 form 784 for specific loop power wiring information.

Examples are shown in the following diagrams:

**SNAP-PS24**



**SNAP-PS24U**



- Connect the ground terminal to ground. Using the removable input power connector on top of the power supply, apply 120 volts of AC power between the two terminals marked AC.

# SNAP Brains

1. Assemble the rack, power supply, and modules according to the directions that came with them.


**CAUTION:** Make certain that you have the correct SNAP rack for the brain you are using. **Using the wrong rack will severely damage the brain.** See page 2 for brain and rack compatibility.

2. Remove the brain from its packaging.
3. Turn off power to the rack assembly.
4. Align the brain connector with the mating connector on the mounting rack, as shown in the diagram at right.
5. Seat the brain onto the connector and use the hold-down screw to secure the brain in position. Do not overtighten.
6. Using Category 5 or superior solid unshielded twisted-pair cable, connect the brain in one of the following ways:

- (Recommended for initial configuration) Connect to a PC directly, using an Ethernet crossover cable.
- Connect to a standard 10BASE-T or 100BASE-TX Ethernet network that has a PC on the same subnet as the brain and does NOT have a Dynamic Host Configuration Protocol (DHCP) server.


Maximum cable or segment length is 100 meters; minimum cable length is one meter.

7. Follow instructions in the brain data sheet or user's guide for communications wiring and jumper settings, if applicable.



# SNAP I/O Modules

Most SNAP input and output modules have a top-mounted, pluggable field connector for easy access when the module is installed on the SNAP mounting rack. The following diagrams show the field connector and the location of pin 1.




## Module Wiring Diagrams

Module wiring diagrams begin on the following pages:


- Digital input modules [page 11](#)
- Digital output modules [page 12](#)
- Analog input modules [page 15](#)
- Analog output modules [page 24](#)
- Serial communication modules [page 27](#)
- PID modules [page 30](#)

## Digital Input Modules

*Wiring for most digital input modules (except SNAP-IDC5-SW and SNAP-IDC5-SW-NC)*




*Wiring for SNAP-IDC5-SW and SNAP-IDC5-SW-NC digital input modules*




**CAUTION:** The SNAP-IDC5-SW and SNAP-IDC5-SW-NC inputs are not intended to be used with contacts that are connected to any external user-supplied voltage or currents.

## Digital Output Modules

### Wiring for SNAP-OAC5 and SNAP-OAC5FM digital AC output modules




### Wiring for SNAP-OAC5MA and SNAP-OAC5-i digital AC output modules







**Wiring for SNAP-ODC5SRC and SNAP-ODC5SRCFM digital DC output modules**




**Wiring for SNAP-ODC5SNK, SNAP-ODC5ASNK, and SNAP-ODC5SNKFM digital DC output modules**




**Wiring for SNAP-ODC5R, SNAP-ODC5R5, SNAP-ODC5RFM, and SNAP-ODC5R5FM dry contact output modules**



**Wiring for SNAP-ODC5MA digital DC output module with manual/auto switches**



**Wiring for SNAP-ODC5-i, SNAP-ODC5A-i, SNAP-ODC5-iFM, and SNAP-ODC5A-iFM isolated digital DC output modules**




**Analog Input Modules**


**Wiring for SNAP-AIARMS analog amps RMS AC/DC input**

Two possible wiring diagrams are shown.

Terminals 3, 4, 7, and 8 share a common connection inside the module. **Make sure you observe polarity** when connecting the second channel. To avoid a potentially hazardous short, double-check wiring before turning on the current to be monitored.




**Wiring for SNAP-AIVRMS analog volts RMS AC/DC input**




Terminals 3, 4, 7, and 8 share a common connection inside the module. **Make sure you observe polarity** when connecting the second channel. To avoid a potentially hazardous short, double-check wiring before turning on the voltage to be monitored.

**Wiring for SNAP-AICTD two-channel analog temperature input**




**Wiring for SNAP-AICTD-4 four-channel analog temperature input**

*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.*



**Wiring for SNAP-AIMA two-channel analog current input**


Since all inputs share a common reference, the module must be installed at the beginning or end of a typical 4–20 mA loop. If you are using both standard and self-sourcing transmitters, either put the transmitters on different modules, or use different power supplies. Do not use standard and self-sourcing transmitters on the same module. This module does NOT supply loop excitation current. See “Loop Power Supply” on page 7.



**Wiring for SNAP-AIMA-4 four-channel analog current input**


*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.*

Since all inputs share a common reference, the module must be installed at the beginning or end of a typical 4–20 mA loop. If you are using both standard and self-sourcing transmitters, either put the transmitters on different modules, or use different power supplies. Do not use standard and self-sourcing transmitters on the same module. This module does NOT supply loop excitation current. See “Loop Power Supply” on page 7.



**Wiring for SNAP-AIMA-i isolated two-channel analog current input**

The two channels are isolated from each other. This module does NOT supply loop excitation current. See “Loop Power Supply” on page 7.




**Wiring for SNAP-AIPM analog power monitoring input**


*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only. For more information about this module, see Opto 22 form #1453, the SNAP-AIPM data sheet.*

**CAUTION:** These terminals share a common connection inside the module. **Make sure you observe polarity** when connecting the second channel. To avoid a potentially hazardous short, double-check wiring before turning on the current to be monitored.


**Measuring AC Line Current with a Current Transformer**



**Standard Wiring Diagram**




**Measuring AC Line Current Greater than 10 Amps**




**Wiring for SNAP-AIMA-iSRC isolated two-channel analog current input**

The two channels are isolated from each other.  
This module DOES supply loop excitation current.



**Wiring for SNAP-AIR40K-4 analog thermistor input**


NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.






**Wiring for SNAP-AIRATE analog rate input**

Two possible wiring diagrams are shown:




**Wiring for SNAP-AIMV-4 and AIMV2-4 analog millivolt inputs**

*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.*




**Wiring for SNAP-AITM and SNAP-AITM-2 analog thermocouple/millivolt inputs**



Since both inputs share the same reference terminal, use isolated probes for thermocouple inputs.



**Wiring for SNAP-AITM-i and SNAP-AITM-2-i isolated analog thermocouple/millivolt inputs**



Since these channels do not share any common connections, grounded sensors and field devices may be used with them.


**Wiring for SNAP-AIRTD analog RTD input**

The SNAP-AIRTD is designed for three-wire connections, shown in the diagram at right.




CAUTION: ACCURACY AND STABILITY WILL BE DEGRADED USING A 2-WIRE RTD

**Wiring for SNAP-AIV two-channel analog voltage input**




**Wiring for SNAP-AIV-4 four-channel analog voltage input**

NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.




**Wiring for SNAP-AIV-i isolated two-channel analog voltage input**



The two channels are isolated from each other. Since these channels do not share any common connections, grounded sensors and field devices may be used with them.


**Analog Output Modules**

**Wiring for the SNAP-AOA-3 single-channel analog current output**




NOTE: THIS MODULE MUST BE USED WITH AN EXTERNAL LOOP POWER SUPPLY


**Wiring for the SNAP-AOV-5 and SNAP-AOV-7 single-channel analog voltage outputs**




**Wiring for the SNAP-AOA-23 dual-channel analog current output**




**Wiring for the SNAP-AOA-25 and SNAP-AOA-27 dual-channel analog voltage output**



**Wiring for the SNAP-AOA-28 dual-channel analog current output**




**Wiring for the SNAP-AOD-29 dual-channel analog time-proportional digital output**



**Serial Communication Modules**

**Wiring for the SNAP-SCM-232 serial communication module**

*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.*




Pinouts for RJ-45 connectors on the SNAP-SCM-232:

1	Not used
2	RX (receive data)
3	TX (transmit data)
4	RTS (request to send)
5	GND (signal ground)
6	Not used
7	Not used
8	CTS (clear to send)

Refer to Opto 22 form #1191, the *SNAP Serial Communication Module User's Guide*, for more information.

**Wiring for the SNAP-SCM-485-422 serial communication module**

*NOTE: Use with SNAP Simple, SNAP Ethernet, or SNAP Ultimate brains only.*



**Pinouts for Two-Wire  
SNAP-SCM-485**

Pin	Port	Description
1	A	Vcc
2	A	TX/RX +
3	A	TX/RX -
4	A	Sig Gnd
5	B	Vcc
6	B	TX/RX +
7	B	TX/RX -
8	B	Sig Gnd

**Pinouts for Four-Wire  
SNAP-SCM-485**


Pin	Port	Description
1	A	Vcc
2	A	TX +
3	A	TX -
4	A	Sig Gnd
5	A	Vcc
6	A	RX +
7	A	RX -
8	A	Sig Gnd

*NOTE: Vcc on the SNAP-SCM-485 is 5 VDC and is supplied by the module itself. Do not use this voltage to power another device, as it can interfere with normal module operation.*

Use the small switches on the top of the module to provide bias or termination on the RS-485 network as required. If the port is physically the first or last device on the RS-485 network, provide termination by moving the Term switch to ON. Also provide bias at one point on the network by moving both the Up and Down switches to ON.

Bias and termination switches are shown in the diagram at right.

Refer to Opto 22 form #1191, the *SNAP Serial Communication Module User's Guide*, for more information.




*NOTE: Vcc on the SNAP-SCM-485 is 5 VDC and is supplied by the module itself. Do not use this voltage to power another device, as it can interfere with normal module operation.*



**Wiring for the SNAP-SCM-W2 serial communication module**

*NOTE: Use with SNAP Ethernet or SNAP Ultimate brains only.*

**SNAP-SCM-W2 Top View**



**Pinouts for SNAP-SCM-W2**

Pin	Port	Color	Description
1	A	Black	Common
2	A	White	Data One
3	A	Green	Data Zero
4	A	--	Not used
5	B	Black	Common
6	B	White	Data One
7	B	Green	Data Zero
8	B	--	Not used

## SNAP PID Module


Connect PID output wiring as shown in the diagram below. If you want to use PID setpoint and process variable analog inputs from external sources with the SNAP PID module, also connect PID setpoint inputs to channel 0 and process variable inputs to channel 1, as shown.

PID output can be 4–20 mA current and 0–10 VDC voltage outputs, both of which share a common negative terminal. PID output is calculated by the module and then sent simultaneously to both current and voltage outputs as a percent of output scale. This PID output can be analog or TPO signals (if TPO is selected, both current and voltage outputs are switched from 0% to 100%).

*NOTE: Use SNAP PID modules with SNAP Ethernet or SNAP Ultimate brains only.*

### Wiring for the SNAP-PID-V module

NOTE: Analog inputs share a common reference and are not isolated from each other.



# Index

## A

- analog input modules
  - power requirements, 5
  - wiring, 15
- analog output modules
  - power requirements, 5
  - wiring, 24

## B

- brain
  - installing, 9
  - power requirements, 5
  - rack compatibility, 2

## C

- current loop power supply, wiring, 7

## D

- digital input modules
  - power requirements, 5
  - wiring, 11
- digital output modules
  - power requirements, 5
  - wiring, 12

## I

- I/O modules
  - analog input, 15
  - analog output, 24
  - basic diagram, 10

- digital input, 11
- digital output, 12
- power requirements, 5
- wiring, 1
- installing
  - brain on rack, 9
  - I/O modules, 10
  - mounting rack, 2
  - power supplies, 4

## L

- loop power supply, 7

## M

- mounting rack
  - wiring, 2

## P

- PID modules
  - power requirements, 5
  - wiring, 30
- power monitoring module, 19
- power supply
  - current loop, 7
  - determining requirements, 4
  - wiring, 4

## R

- rack for I/O modules
  - wiring, 2

## S

### serial modules

- power requirements, 5
- wiring, 27
- SNAP-AIARMS, 15
- SNAP-AICTD, 16
- SNAP-AICTD-4, 17
- SNAP-AIMA, 17
- SNAP-AIMA-4, 18
- SNAP-AIMA-i, 18
- SNAP-AIMA-iSRC, 20
- SNAP-AIMV2-4, 21
- SNAP-AIMV-4, 21
- SNAP-AIPM, 19
- SNAP-AIR40K-4, 20
- SNAP-AIRATE, 21
- SNAP-AIRTD, 22
- SNAP-AITM, 22
- SNAP-AITM-2, 22
- SNAP-AITM-2-i, 22
- SNAP-AITM-i, 22
- SNAP-AIV, 23
- SNAP-AIV-4, 23
- SNAP-AIV-i, 24
- SNAP-AIVRMS, 16
- SNAP-AOA-23, 25
- SNAP-AOA-25, 26
- SNAP-AOA-27, 26
- SNAP-AOA-28, 26
- SNAP-AOA-3, 24
- SNAP-AOD-29, 27
- SNAP-AOV-5, 25
- SNAP-AOV-7, 25
- SNAP-IDC5-SW, 11
- SNAP-IDC5-SW-NC, 11
- SNAP-OAC5, 12
- SNAP-OAC5FM, 12
- SNAP-OAC5-i, 12
- SNAP-OAC5MA, 12
- SNAP-ODC5A-i, 15
- SNAP-ODC5A-iFM, 15
- SNAP-ODC5ASNK, 13
- SNAP-ODC5-i, 15
- SNAP-ODC5-iFM, 15
- SNAP-ODC5MA, 14
- SNAP-ODC5R, 14
- SNAP-ODC5R5, 14
- SNAP-ODC5R5FM, 14
- SNAP-ODC5RFM, 14
- SNAP-ODC5SNK, 13
- SNAP-ODC5SNKFM, 13
- SNAP-ODC5SRC, 13
- SNAP-ODC5SRCFM, 13
- SNAP-PID-V, 30
- SNAP-SCM-232, 27
- SNAP-SCM-485, 28
- SNAP-SCM-W2, 29

## W

- wiring diagrams for SNAP I/O, 1